



PREPARE FOR YOUR SAW JOB

- Prepare a relatively level and clear site.
- The sawmill and the truck combined are 45' long. Your site should provide enough space for lining up the logs to roll on to the lift arms of the sawmill.
- For offloading, it would be helpful to you if you could load onto a trailer, wagon or truck. Or have a space prepared nearby to stack the cut lumber, for easy movement to the final stacking site.
- It is your responsibility to provide manpower for offloading cut boards. Two persons will make the job go more smoothly. Boards can be very heavy, a 2"x18"x10' oak plank will weigh about 150+ pounds.
- Prep the logs by cleaning mud, dirt and gravel from the bark. Trim logs, removing branch stubs. Line up logs side by side for easy roll on to the mill's lift arms.